

CRAWLTEK

REVOLUTION

491 W. GARFIELD AVE., COLDWATER, MI 49036 • 517.278.1039
CRAWLTEKREVOLUTION.COM • E-MAIL: SALES-CRAWLTEK@RIDEFOX.COM

INSTALLATION INSTRUCTIONS

BLAZE FRONT BUMPER SKIDPLATE

JL19011

FOR USE WITH ALL
2018-2024 Jeep Wrangler JL, 2020-2024 Jeep Gladiator JT



CrawTek YouTube

PLEASE READ THROUGH INSTRUCTIONS BEFORE INSTALLING

2024-12-06

WHAT'S IN THE BOX?

PLEASE VERIFY KIT CONTENTS BEFORE BEGINNING INSTALLATION

PART #	Qty	DESCRIPTION
6323	1	BLAZE LOWER FRONT BUMPER SKID PLATE - DRIVER
6324	1	BLAZE LOWER FRONT BUMPER SKID PLATE - PASS
6325	1	BLAZE LOWER FRONT BUMPER SKID PLATE CENTER SECTION
C0062	1	BOLT PACK - JL BLAZE FRONT BUMPER SKID PLATE
	8	1/4"-20 X 3/4" BUTTON HEAD HEX DRIVE SCREW, BLACK-OXIDE 18-8 SS
	8	1/4"-20 ZINC SERRATED HEX FLANGE NUT
C0060	1	BOLT PACK - JL PYRO FRONT BUMPER SKID PLATE / MOUNT BOLTS
	4	7/16"-14 X 1-1/4" GRADE 8 YELLOW ZINC FINISH HEX CAP SCREW
	4	7/16" YELLOW ZINC FINISH STEEL SAE FLAT WASHER
	4	7/16"-14 ZINC FINISH SERRATED FLANGE NUT



TOOLS REQUIRED

5/32 ALLEN HEX WRENCH
5/8", 7/16", 11/16" SOCKET OR WRENCH
TORQUE WRENCH

PRE-INSTALLATION NOTES

1. THIS BUMPER SKID PLATE IS DESIGNED TO BE USED WITH THE BLAZE BUMPER. IT HAS NOT BEEN FITMENT TESTED FOR THE STOCK BUMPER.

INSTALLATION OF THE PYRO FRONT BUMPER SKID PLATE

STEP 1 :

ASSEMBLE THE 3-PIECE SKID PLATE USING THE PROVIDED 8X BOLTS AND FLANGE NUTS AS SHOWN.



STEP 2:

WITH THE MOUNTING PLATES BETWEEN THE FRAME HORNS, INSTALL 2X BOLTS AND WASHERS ON EITHER SIDE IN THE TOP HOLES TO HOLD PLATE IN PLACE.



STEP 3:

INSTALL THE SERRATED FLANGE NUTS USING CLOSED END WRENCH TO REACH THE TOP BOLTS WITH THE NUT. LEAVE LOOSE. TIP: USE SOME TAPE TO KEEP NUT FROM FALLING OUT OF WRENCH.



STEP 4:

INSTALL THE BOTTOM BOLTS AND WASHERS. INSTALL NUT AND TIGHTEN ALL FOUR. TORQUE TO 52 FT-LBS.





YOU'RE NOT DONE YET!

Thank you for your new CrawlTek Revolution purchase! Follow us on facebook for up to date coverage of new product releases. We love feedback, if you have any questions about the installation or parts were missing please contact us at sales-crawltek@ridefox.com or call us at 517.278.1039.

*Be sure to show off your jeep to the rest of the CrawlTek Revolution online.
Find us on facebook and instagram to keep up on new products, upcoming events and more action.
Tag us @crawltek for a chance to get featured*

