

Installation Instructions

Fox 2.5 Performance Series Shock Absorbers

FOX98624154/ FOX98624155/ FOX98624157

Read and understand all instructions and warnings prior to installation of product and operation of vehicle.

It's recommended that this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

INSTALLATION INSTRUCTIONS

1. Park vehicle on a clean, flat, and level surface. Block the wheels for safety.
2. Remove old shocks from the vehicle. Retain OE hardware.

Note: If this installation is being performed on a hoist, or with the axle hanging, the axle must be well supported. Keep all hardware that is removed.

» FRONT INSTALLATION

3. The front shocks will be installed with the bushings oriented so that the body is further away from the frame of the vehicle. The shock should be installed with the body up. Make sure the longer half of the bushing is toward the frame.



4. The lower mount will be installed with the shaft offset away from the body, as shown below.



5. Tighten upper mount hardware to 80 ft-lbs and lower mount hardware to 75 ft-lbs.

» REAR INSTALLATION

6. Rear shocks should be installed with the body up and the black roost guard down.
7. Tighten upper mount hardware to 80 ft-lbs and lower mount hardware to 75 ft-lbs.
8. Be sure to check clearance of the shock through full wheel travel to ensure there is no contact between the shock and any other part.
9. Recheck all fasteners after 500 miles of driving.