

JKS[®]

INSTALLATION INSTRUCTIONS

Product: Front Coilover Conversion Bump Stops
Part Number: JKS2512

**Applications: Wrangler, JL 2018-19 Coilover Kit
Only**

517-278-1226 • jks@ridefox.com • www.jksmfg.com
491 W. Garfield Avenue, Coldwater, MI 49036

Welcome

CONGRATULATIONS on purchasing a set of Bump Stops got your front coilover conversion from JKS Manufacturing. We are committed to providing you with the best products available and your satisfaction is our first priority.

PLEASE READ these Installation Instructions carefully, and save them for future reference, as they contain important installation and maintenance information.

Important

Tools Required

- Standard Allen Wrench Set
- Torque Wrench

** Asterisk denotes tools that are not required for some applications. Thoroughly read instructions first to determine which tools will be required for your application.*


Parts

	Description	QTY
A	Front Coilover Bumpstop Bung	2
B	Bump Stop	2
C	Cap	2
D	3/8"-16 x 4" Socket Cap Bolt	2

Installation

❑ 1. INSTALL BUMP STOP

- Place the cap onto the top of the bump stop tube on the front coilover frame bracket
- Take the 3/8" socket cap bolt from bolt pack J147 and put it through the bump stop than the bump stop bung.
- Place loctite on the bolts threads and insert the assembly into the bottom of the bump stop tube on the front coilover frame bracket.
- Tighten the bolt with a 5/16" Allen wrench. While using a 3/8" Allen to hold the cap. It will screw into the cap. Torque to 20 ft-lbs.



Maintenance

Regular cleaning with pressurized water is recommended.

©2020 JKS Manufacturing, Inc
Revision Date 2/28/2020